



Several measurements are required to make the cover fit properly. After measuring the sail on the boom, start with the following:

**Measurement A:** from 3 to 4 inches below the boom on the mast, measure up 1 or 2 inches above the headboard.

**Measurement B:** is the circumference of the mast including any lines that may lay along side, add 1 ½ inches for allowances.

**Measurement C:** If the headboard is rigid, measure its length plus 1 inch.

**Measurement D:** is measured from the center of the mast diagonally to the fullest part of the bulk of the sail at approximately a 45 degree angle.

**Measurement E:** is measured from the center of the mast back to the same finish point as "D".

**Measurement F:** at each 39 inch section, measure the circumference, loosely, divide this in half and add 2 inches.

**Measurement G:** every 39 inches to the end of the cover, the last segment is measured at it's actual length.